



Cleaning instructions Via Sensus®

1. Cleaning agents:

1.1. Maintenance cleaning

We recommended in addition to water, the use of a commercially available neutral detergent with a pH 6 to 8.

1.2. Basic cleaning

We recommended the use of a plastic compatible alcoholic cleaner. The use of a weak alkaline cleaner with a pH 8 to 9, is likewise also suitable for the basic cleaning.

The ceramic moulded parts can in the event of stubborn dirt or stains, e.g. during outdoor use, be carefully cleaned with acetone or denatured alcohol. These special cleaning agents may, however, only come into contact with the ceramic and should not to be used for the general cleaning of the subsurface!

PLEASE NOTE:

We strongly recommended abstaining from the use of strongly acidic and strongly alkaline cleaners as well as solvents, since these will corrode and destroy the materials used.

We likewise also recommend abstaining from the use of abrasives and other.

Furthermore, it is recommended for safety purposes to abstain from the use of film-forming detergents.

Cleaning instructions Via Sensus®

2. Cleaning method:

2.1 Maintenance cleaning:

The recommended cleaning procedure is manual cleaning with the use of water and rags / wipers.

2.2 Basic cleaning:

Blow-off steam (no high pressure) can also be recommended for the basic cleaning.

PLEASE NOTE:

We recommend abstaining from the use of high pressure cleaners, scrapers, and other devices that can damage the surface or parts of the parcours of the foot reflexology zones, especially also from the use of equipment such as shovels, pecks, heavy sweeping or removal equipment, as well as the subjection of the mould parts to strong lateral forces.

Access into the Via Sensus with shoes is only permitted if they are clean and have a soft, clean sole.

No liability will be accepted for damage caused by acidic or caustic cleaning agents or improper cleaning procedures.